

# Fishing boat

1150 4003

## Water connection:

Ø75mm (PVC DN 65)

## Water consumption:

8m<sup>3</sup>/h

## Water pressure:

1-1,6 bar

## Minimum water depth:

Not relevant

## Maximum water depth:


300mm

## Mounting instruction:

Aqua Drolics system B & D-1

## Suitable for age:

0-4  5-8  >9



Turn on the LED lights by turning the wheel.

Activate the water on the deck by using the push button.

Use the climbing rope to get into the boat.



# Fishing boat

1150 4003

